DIGITAL Photo Academy



By Panasonic LUMIX

Icons on your camera – use them to their fullest potential!

		5112	In to their runest potential!
	Play Mode	2	Fluorescent 2
	Snapshot Mode	- • •	Tungsten
BS	BESTSHOT Mode	MWB	Manual White Balance
Α	Aperture Priority AE mode		Single Shot
S	Shutter Priority AE mode	Ĵ	High Speed Continuous Shutter
Μ	Manual Exposure Mode	J	Normal Speed Continuous Shutter
Þ	Movie Mode		Multi Continuous Shutter
BS	BESTSHOT Movie Mode	AEB	AE Bracketing
$\mathbf{\Psi}$	Voice Recording mode	WBB	WB Bracketing
4	Flash On	AFB	Focus Bracketing
E	Flash Off	MB	Multi Bracketing
\odot	Red Eye Reduction	10s	10-second Self-timer
*	Macro Mode	8) 25	2-second Self-timer
∞	Infiniti Mode	No. X3	Triple Self-timer
MF	Manual Focus	()	Remote controller
PF	Pan Focus (Movie mode only)	25	Remote controller and 2- second timer
2	Cloudy	₽	Multi (metering)
- (Daylight	\bigcirc	Center Weighted (metering)
́≴wв	Flash	•	Spot Meter
	Shade	→ 🕰	Built-in Memory selected for data storage
派 1	Fluorescent 1	→ [_]	Memory Card selected for data storage

No matter what brand of camera you use, Panasonic's Digital Photo Academy will help you get the most out of your equipment and take the best pictures possible!