## **DIGITAL** Photo Academy

## FUJ:FILM CAMERA CONTROLS

## By Panasonic LUMIX

Icons on your camera – use them to their fullest potential!

	Beach		Picture Stabilization	<del>7</del> 1	WB –Daylight Fluorescent
<i>‰</i> 🔅	Fireworks	AUTO	Auto Flash	₩ź	WB – Warm White Fluorescent
*	Flower Close Up	$\bigcirc$	Red-Eye Reduction	₩3	WB – Cool White Fluorescent
	Landscape	4	Forced Flash	- <u></u> Ċ-	WBincandescent
*	Macro	<b>(£</b> )	Suppressed Flash		Natural Light
♪\$ OFF	Museum	S <b>4</b>	Slow Synchro Flash	€	Natural Light & Flash
C	Night Scene	O SLOW	Red Eye & Slow		Power Management
Y	Party	<b>Č</b> 10	10 Second Timer	+	Exposure Compensation
	Portrait	<ul><li>€2</li></ul>	2 Second Timer	[0]	Multi meter
*	Sport	<u>ů</u>	Continuous Mode	[•]	Spot meter
	Snow	■」	Long Period Continuous Shooting	[]	Average meter
- <b>*</b> -	Sunset	Ō	Final 2 Continuous Shooting		
TEXT	Text	<u>o</u>	Top 2 Continuous Shooting		
۰	Underwater	WB	White Balance		
AUTO	Auto Shooting Mode		Custom White Balance		
	Intelligent Face Detection	*	WB – Shooting outdoors in good weather		
<b>D</b> M	Manual	Р.	WB – Shooting in shade		

No matter what brand of camera you use, Panasonic's Digital Photo Academy will help you get the most out of your equipment and take the best pictures possible!