



CAMERA CONTROLS

Icons on your camera – use them to their fullest potential!

	Auto		Continuous Mode		Vivid Color
	Playback		Macro		Sport
	Movie	WB	White Balance		Children
	Image Stabilization	AUTO	WB – Auto		Indoor
SCN	Scene		WB – Daylight		Leaf
	Portrait		WB – Cloudy		Snow
	Panoramic		WB – Fluorescent		Sunset
M	Manual		WB – Fluorescent CWF		Fireworks
	Auto Flash		WB – Incandescent		Glass
	Red Eye Reduction		WB – Manual		Museum
	Forced Flash	BQ*	Best Quality		Landscape
	Flash Off	FQ*	Fine Quality		Night Landscape
	Slow Synchro Flash	NQ*	Normal Quality		Night Portrait
	Red Eye & Slow Synchro	Goff	Color Adjust Off		Spot AE
	2-second Timer	BW	Black & White		Center-Weighted AE
	10-second Timer	SE	Sepia		AI AE

No matter what brand of camera you use, Panasonic's Digital Photo Academy will help you get the most out of your equipment and take the best pictures possible!