
























































Icons on your camera – use them to their fullest potential!

	Auto Mode		Auto Flash		Date Stamp
	Movie Mode		Fill Flash		Exposure Compensation
	Program Mode		Red Eye Removal		Picture/Video Size
	Aperture Priority		Flash Off		White Balance
	Shutter Priority		Center Focus		Requires Long Exposure
	Manual Mode		Center Wide Focus		ISO
	Custom		Side Focus		Focus Zone
	Setup		Center & Side Focus		Color Mode
	Language		Left & Right Focus		Long Time Exposure
	Scene Mode		Information Button		Set Album
	Portrait		Albums		Video Length
	Sports		Add to Favorites		Liveview
	Landscape		Favorites Album		Return
	Close-Up / Macro		Remove from Favorites		Orientation Sensor
	Children		Self-timer		On
	Party		First Burst		Crop
	Night Portrait		Last Burst		Multi-Up (Thumbnails)
	Beach		Slide Show		Locked

	Snow		Perfect Touch Tool		Delete
	Fireworks		Copy		Date / Time
	Self-Portrait		Print		Email
	Backlight				

No matter what brand of camera you use, Panasonic's Digital Photo Academy will help you get the most out of your equipment and take the best pictures possible!